

Replace Sensors

The process to replace a sensor (motion detector, door sensor) is not intuitive. It is done from one of the alarm panels, and will probably require referring to the [installation manual](#). From that information, the following steps should be executed.

1. Delete the zone that is affected
2. Secure the new sensor
3. Install a battery in the new sensor, and, with a door sensor, ensure there is a magnet alongside as if it were installed on the door
4. Follow the procedure in the wireless guide to enroll the new sensor (identify the zone placement, enter the ID of the sensor)
5. Update the equipment assignment spreadsheet on the main file server.
(T://Technology/Environmnet and Security/Security System/DSC)

Revision #3

Created 19 June 2023 10:35:32 by Admin

Updated 19 June 2023 11:01:39 by Admin